


KEY NOTES



- ① SHEATHING
- ② PAREX USA SHEATHING JOINT TAPE EMBEDDED IN PAREX USA WATER RESISTIVE & AIR BARRIER COATING
- ③ PAREX USA WATER-RESISTIVE BARRIERS (SEE NOTE 1)
- ④ PAREX USA WEATHERFILL (AIR-SEAL)
- ⑤ VENTED TRACK (BY OTHERS)
- ⑥ PAREX USA SHEATHING JOINT TAPE SHINGLING OVER VENTED TRACK
- ⑦ EXPANDED POLYSTYRENE INSULATION BOARD
- ⑧ PAREX USA EPS BASE COAT & ADHESIVE
- ⑨ PAREX USA REINFORCING MESH EMBEDDED IN PAREX USA EPS BASE COAT & ADHESIVE
- ⑩ MECHANICAL FASTENERS (SUPPLIED BY OTHERS) THROUGH EPS BASE COAT AND MESH INTO FRAMING AS REQUIRED BY PAREX USA
- ⑪ PAREX USA MASONRY VENEER ADHESIVE
- ⑫ ADHERED VENEER
- ⑬ GROUT
- ⑭ MIN. DISTANCE PER APPLICABLE BUILDING CODE

**MVS-CI T1.02 TERMINATION AT GRADE WITH VENTED TRACK**

MASONRY VENEER CONTINUOUS INSULATION DRAINAGE SYSTEM

DATE: 4/1/16  
SCALE: N.T.S.

**NOTES:**

- 1. Parex USA Water-Resistant & Air Barrier options: **A.** WeatherSeal Spray & Roll-On or WeatherSeal Trowel-On (vapor permeable).  
**B.** WeatherBlock SP1 Spray & Roll-On (vapor impermeable).
- 2. Follow code requirements for adhered veneer dimensions and weights.
- 3. Sawn dimension lumber floor joist may require an expansion joint at the dissimilar substrate transition.
- 4. For alternate veneers contact Parex USA Technical Services Department.

**Disclaimer :** The design, specifications, and construction shall comply with all local building codes and standards. Parex USA installation guidelines are for general information and guidance only and Parex USA specifically disclaims any liability for the use of this design, and for design, engineering, or workmanship of any project. The assembly shall be designed to prevent condensation within the assembly. The designer and the user shall provide final drawings and specifications. Products shown other than those manufactured by Parex USA are shown for clarity of the Parex USA product only. Contact the manufacturer of such other products for installation instructions.